

EasyGo.ie Rapid Charger Operating Instructions

Charging your car with the Veefil-RT fast charger is safe, secure, and easy to do with industry standard plugs and a simple interface that guides you through the charging process.

The Veefil-RT fast charger offers two different charging plugs, the CHAdeMO and the Combined Charging Standard (CCS).



Activation security

Veefil-RT has been designed to activate and secure your individual charging session through RFID Fob recognition or APP. Once activation authorisation has been recognised you have a certain timeframe to begin your charging session.

Using the interface panel

The top half of the panel has icons and buttons that control the charging session. The icons will either visually flash on and off to prompt an action or selection, or show as a solid light to indicate the current mode.

The lower half of the panel shows charging information.


At certain times you hear audio feedback to assure you that certain functions are successful.

The minutes shown on the display show how long your car has been charging.

You will have ample time to make your selections, however if the charger has been idle for too long without making a selection it returns to being available for other users.

At any stage, return the plug to the Veefil-RT plug holder to end your charging session.

The interface panel



1. Connect plug to car

Icon flashes when the unit is available for use.

2. Activation

Swipe your card over this area or use your APP or SMS to activate the user interface, and to also unlock a charging session.

3. MAX or %

Toggle button may allow selection between the % indicated and the maximum charge amount.

4. Start

Push to start the charging session.

5. Stop

Push to stop the charging session.

6. Return plug to charger

Flashes when the charging session is complete and the plug should be returned to the plug holder.

7. Not in service

Icon will be lit when the charger is not in service.

8. Locked symbol

Lit when a charging session is in progress and the interface panel is locked.

9. Charging indicator

Will glow when a charging session is in progress.

10. LED information displays

Displays minutes, battery percentage during charge, kilowatts delivered, fee charged.

Emergency Stop

In case of emergency, press the emergency stop button to shut down and secure the Veefil-RT.